



FLEXIBLE CONDENSATE DWV P-TRAP

For HVAC Systems and Air Conditioners | 3/4" Pipe and Hub Connections

STEP BY STEP INSTALLATION INSTRUCTIONS



1

Dry fit the new condensate trap to ensure correct fit. Mark parallel lines on the existing pipe matching both ends of the new trap.



2

Measure 3/4" down from the dry fit mark and make a 2nd mark at each end. This is where you will cut.



3

TURN POWER OFF

Switch off power directly at the HVAC unit or the corresponding circuit breaker.



4

Using a PVC pipe cutter or hand saw, cut directly over the 2nd mark on each end and remove the old trap.



5

Using a utility knife or deburring tool, scrape away plastic fragments or burrs.



6

Loosen the screw on each of the hose clamps. *Remove included bushing if installing over hub.



7

Slide each end of the new condensate trap over the corresponding pipe. Hand tighten with a nut or screw driver.



8

Prime the trap by pouring 3-6 ounces of tap water directly into the line.



9

Turn power back on. Check for leaks. Installation is now complete.